



DDNS GUIDE

1. Create an account with www.no-ip.com
2. Once created, log in to no-ip.com and click "Hosts/Redirects"
3. Click Add Host and fill in the following fields:
 - a. Hostname: ***youchoosesomething.no-ip.biz***
 - b. Host Type: ***DNS Host (A)***
 - c. IP Address: ***(will self-populate)***
 - d. Assign to Group***(not Required)***
4. Click Create Host.

That's all that's required on the **no-ip.com** setup.

5. On the DVR, login as an administrator, go to settings, go to network, select DDNS from the options available and enter these details.
 - a. DNS1: 208.67.222.222
 - b. DNS2: 208.67.220.220
 - c. Under advanced go to **DDNS**. Check the box to enable. Double click "**DDNS**" and enter the details below:
 - i. DDNS Type: **NO-IP DDNS**
 - ii. Enable: **(check this box)**
 - iii. Server IP **dynupdate.no-ip.com**
 - iv. Port: **80**
 - v. Domain Name: **(The Hostname you chose above on step 3.a)**
 - vi. Username: **(The username you registered on step 1)**
 - vii. Password: **(The Password you chose on step 1)**
 - viii. Alive Interval: **(the number of seconds between updates: default 300sec)**
 - d. Click Save.
6. Click Save Again and exit to the main menu.

From now on, connect to this site by entering the hostname rather than an IP address, this applies to phone software, PC/MAC software and Web Browser interface.